

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.

- (1) Pedal Board face plate (Black or Silver)
- (2) 10/32x1/2" Button head S/S screws - MC92949A265
- (1) Mounting Bracket (Black)
- (2) 10/32 nutserts -C95105A135



1. Remove gas pedal from car by releasing the tension clip on the side of the pedal as shown in photo 1 and sliding the gas pedal to the left as shown in photo 2.
2. Slide the pedal board bracket under the dead pedal as shown in photo 3. This bracket has a special cut out in the end that will lock in place behind the factory dead pedal.
3. Attach the other end of the bracket behind the gas pedal mount using the factory bolt. See photo 4.
4. Re-install the gas pedal.
5. Install the pedal board using the supplied (2) button head screws as shown in photo 5.
6. Enjoy your new Rennline product.