

INSTALLATION INSTRUCTIONS FOR THROTTLE EXTENSIONS

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

Parts List

- (4) 8/32 x.5" S/S Oval Screw - MC91802A194
- (4) 8/32 S/S Nylon Nut - MC90101A009
- (1) (Heel + Toe kit) Throttle Extensions
- (1) Backer Plate

Step 1

A. Attach throttle extensions to the backer plate using the supplied #8-32 X .5" S/S screws and nuts.



Step 2

A. Install the assembled throttle extension unit between your Pennline rubber grip throttle cover and your factory plastic pedal. Install using the hardware supplied in your pedal cover kit.

